

## RIBBON BLENDER

This mixing unit is ideal for mixing of Broth and Talc in the Bio Fertilizer production Units and also used in various other application like mixing or blending of spice powder, masalas, colours etc.

This is a horizontal unit, blending chamber made of thick gauge stainless steel 304 quality sheets. Provided with a top loading full size shutter and bottom opening with shutter. Collection tray made of S S Sheet provided in the bottom of the unit. This unit is equipped with a TEFC motor coupled with suitable heavy duty worm type gear box to bring down the RPM to 75 - 90 range. The entire unit is mounted on M.S. C channel frame. Supplied with DOL Starter. Top loading shutter is interlocked with shutter operation.

Cat. No.	Motor	Capacity
PRB-01	2 HP	40 Kg.
PRB-02	3 HP	50 Kg.

Heavy duty models are supplied with 415 V AC 50Hz motor.